

How to update **GSM-batcorder** firmware

The GSM-batcorder-firmware is continuously developed by ecoObs and of course the updates are free of charge. At our homepage www.ecoobs.com you can find all relevant data for a download. We recommend to sign up for our newsletter be informed about latest updates.

The software updates for the GSM-batcorder can be installed with a SD card. The current software version of your GSM-batcorder is shown in the lower right corner of the screen when the device is started displayed as **Hxxx** for the hardware version and **Sxxx** for the software version. It takes only a few steps to update the software. But it is highly important to follow each step exactly, as an update failure can make the GSM-batcorder inoperative!

Please note: Only the software (**Sxxx**) can be updated via SD card. The hardware version (**Hxxx**) can only to be updated by ecoObs.

Requirements

For the update you need a SD-card, which has already been accepted by the GSM-batcorder. The GSM-batcorder supports SDHC-cards and SDXC-cards with a capacity up to 256 GB. The cards do not need a specific speed level.

Before the GSM batcorder is able to use the SD memory card it has to format it. Therefore after inserting the correctly formatted SD-memory-card (exFat or NTFS) into the GSM-batcorder you will be asked to carry out another internal formatting process.

If the GSM batcorder refuses to format the SD memory card with the message “No valid file system” you have to format the SD memory card again on your PC as “exFAT” or “NTFS”. (MAC: Format: exFat, Schema: Master Boot Record)

Please **read** each step thoroughly **first, before executing** the update!



Warning: Deactivate all kinds of programs, which could access the SD-card in your computer unwanted and without any user interaction, such as virus scanners etc.

Update

Step 1: Prepare the SD memory card with the GSM-batcorder

Insert the SD-card into the GSM-batcorder and erase all data either with the **erase function** in the **MAIN** menu (press **Fn + (▲)**) or by choosing “**Continue**” at the start of the GSM-batcorder when a message is displayed that the SD card has to be erased. (This request is made, when the SD-card contains for the GSM-batcorder unknown data!)

Step 2: Load update file onto the SD-card

Remove the SD-card from the GSM-batcorder and insert it into your computer's SD-card-slot. Copy the update file from the computer onto the SD-card. (Of course before you can do this, you have to download the file from our homepage onto your computer first. Be sure, that you copy the right file: **For the GSM-batcorder!**).

Do not change anything else on the card, that means do not erase, shift or copy any further files onto the SD-card! Also you have to make sure that no other programs try to have access to the SD-card while inserted in your computer as mentioned before! Remove the SD-memory-card as soon as you have copied all needed update files from your computer onto the SD-card.

Step 3: Firmware Update

Insert the SD-card into the batcorder again. Start the GSM-batcorder and follow the instructions shown on the display. If the update has been successful, the new software number is now shown at the right bottom of the display (**SXXX**).

Note: With this SD-card you can now directly update other GSM batcorder - you do not have to follow step 1 and step 2 again!

Possible Errors

The GSM-batcorder has been updated, but the device will not start or behaves undefined:

The update has failed, possible reasons may have been for example: wrong download file, defective card or unnoticed access onto the SD-card while inserted into the computer.

If the update fails you will have to send your device in.