





HOMEPAGE

PRODUCTS ~

NEWS

DOWNLOAD

ORDERING

SUPPORT ✓

SERVICES ~

ABOUT US

CONTACT

DATES - GSM-BATCORDER 1.0 ONLY

You are here: Home » Products » Hardware » GSM-batcorder » Updates – GSM-batcorder 1.0 only

TABLE OF CONTENTS



Please use appropriate batcorder firmware according to your GSM-batcorder.

Using other firmware versions – for example 3xx with batcorder 2.0 – can destroy your hardware beyond repair!

DOWNLOAD

MD5 hash of the file GSM1_122.bin: 5832cb862cf6b9f1450dc08807f8e9c3

GSM-batcorder - Update to SW122 📥

UPDATES - GSM-BATCORDER 1.0 ONLY

Find changes, additions etc through firmware updates

Inhalt:

- 1. Changes to SW112 to 114
- 2. Changes SW121
- 3. Changes SW118
- 4. Changes SW117
- 5. Changes SW115
- 6. Changes SW111
- 7. Changes SW110
- 8. Changes SW109 9. Changes SW108
- 10. Changes SW107
- 11. Changes SW106
- 12. Changes SW105
- 13. Changes SW104

Changes to SW112 to 114

Add New SIM return "Access denied" will get handled

When USB is activated while the batcorder sleeps the timer ode could be disturbed

added support for new GSM-batcorder 1.0-4G

status SMS now without character limitation

Add SMS now with date/time of sending hardware version added to SMS Add Repair of some sd errors in FAT table Add

Changes SW121

Update Smaller optimisations

Changes SW118

Update Stability update Changes SW117

Update Stability update

Changes SW115

Fixed If run without 12V power supply a loss of USB power can cause an SD card error

Add Improved handling of USB on/off when run without 12V power supply

Changes SW111

Fixed Last ten-digit of prepaid amount was sometimes cut in SMS

Changes SW110

Add Removed SD card recognised in 10 minute counter

Sendung wrong filter parameters will result in correct SMS now

Firmware recognises hardware revision starting with SN900

Add Improved logfile readability

Changes SW109

Charging of external batteries via USB sometimes didn't work properly

ixed If the sd-card was removed in timer active mode while a RPi was connected, a new start was necessary to recognise

card agair

Add Prepaid cards of Vodafone & Telekom show prepaid amount

Reduction of display lightning to prolong runtime

Add Logfile now gets timestamp of last change

Update Battery voltage measurement when sending the daily SMS is improved

Update Logfile entry when timer stops due to missing microphone was improved

Changes SW108

Add After an unintentional hardware reset timer is activated again. The logfile contains an entry: "Timer restart after

ınintentional hardware reset."

Update The SMS "TIMER MANUALLY TURNED OFF" is now sent with date and time.

Add If on screen menu is chosen to diable a running timer, an SMS is sent noting manual turn off.

Fixed If in mode "Waiting for timer" (yellow screen) a connected USB device powers down, the batcorder will not enter

unpredictable behaviour.

Add New SMS-command: "GSM ACTIVATE TIMER". This activates the timer if the batcorder is waiting in settings screen.

Fixed Various other bug fixes

Changes SW107

Update Simplified changing SD card while the device is waiting in timer mode. The card can be swapped and will be automatically formatted. An SMS is sent with content "SD CARD REMOVED". If the device is then turned off, a second S is sent with "batcorder has been turned off manually" or "Timer manually turned off" respectively.

Update Inland roaming SIM card supported now

New SMS command for starting TSL value calibration: "GSM CALIB TSL". If the device has access to the logfile, it adds

entry as well.

date Logfile entry at timer end if no 12V main power supply is available was changed to "No 12V supply found. BC switche

into....." for solar / battery only use.

Add If timer start is cancelled due to too low TSL value or missing microphone, the logfile now states "TIMER START

ABORTED DUE TO MISSING OR LOW TSL!

Fixed If PUK is needed, a correct message appears on screen now.

The status SMS is now correct if no sd card is inserted or the USB port is active.

Changes SW106

Add You can now change the target phone number by sending an SMS from the new phone with content: GSM SEND ME

SMS

Fixed Minimum temperatur in status SMS was not reseted daily

Fixed Voltage display was sometimes wrong

Fixed Noise filter was sometimes not set to maximum

Add Noise filter now features ON / OFF only

Add Noise filter setting per SMS is now done using "GSM SET NOISEFILTER" + ON/OFF

Changes SW105

Add Querying the settings by SMS will now send the device time as well

Add New submenu within autodetect allows setting the MCF, as well as toggling USB charging and "Missing power adapt

SMS

Update A symbol now indicates if charger is connected but inactive (empty symbol)

Add SMS-query regarding battery status now gives a correct -.-- if no battery is connected

Changes SW104

Fixed The screen waiting for start time (yellow) now does not show voltage if no battery is connected.

Fixed When starting without battery no SMS sending is tried if no SIM card is installed

Fixed SD card size is now calculated correct

Fixed After sending a message the batcorder is immediately responsive again

Fixed Noise filter value is now always stored

ixed Negative temperatures are displayed correctly

Add AC-adaptor down message can be activated / deactivated sending a SMS with: GSM SET AC DOWN SMS OFON or

GSM SET AC DOWN SMS OFF

ecoObs GmbH Hermann-Kolb-Str. 35b 90475 Nürnberg

HARDWARE SOFTWARE SUPPORT BATCORDER BCADMIN Orders GSM-BATCORDER **BCANALYZE** +49 911 3768053 WIND TURBINE EXTENSION **BATIDENT BOX-EXTENSION** Software / usage MINI-BATCORDER **SERVICES** +49 251 96195095 MAST-MICROPHONE (14 to 17 german time) **BATLURE CALL ANALYSIS** BATCOUNTER Hardware CONSULTING +49 911 3768054 **CUSTOM SOFTWARE** TRAINING TALKS

SPECIAL TECHNICAL SOLUTIONS

© 2009 - 2025 - ecoObs GmbH - All rights reserved.

CONTACT IMPRINT TERMS OF SERVICE PRIVACY POLICY SITE!