

mini- batcorder

www.ecoObs.de

1.0



START/STOP



Battery:

-  *Fully charged*
-  *Recharge soon*
-  *Recharge*

Memory:

-  *Enough capacity*
-  *Low capacity*
-  *No free memory*

GPS:

-  *GPS signal*
-  *Clock only*
-  *No signal*

